

STATCLEAN TECHNOLOGY (S) PTE. LTD.

30 Kaki Bukit Road 3, # 03-12/13/14, Empire Technocentre, Singapore 417819. Tel: 65-6746 2706 Fax: 65-6746 3045 / 65-6746 3755 Email: sales@statclean.com Website: www.statclean.com

Cordless Wrist Strap (STWS-CORDLESS)

This is a high-tech wrist strap that utilizes the Corona principle to harmlessly drain off all static electricity generated by human body. This cordless Wrist Strap will give you a complete freedom of movement in your work place.

Wrist Band: Elastic and adjustable with conductive filament. The stainless steel back of the wrist strap provide good conductivity to eliminate Static Charges generated.



- Color: Sky Blue
- Size: Adjustable and elastic to fit all
- Application: Provide safe and reliable ground for personnel at work.

For function checking method, only a multi-meter is required to check dissipating function.

| EASY PROCEDURE FOR EFFECTIVE TESTING | | |
|--------------------------------------|-------|---|
| Test-Point pair | | Electric Resistance |
| GOOD | A - B | 10 to the power of 6 ohm $< R < 10$ to the power of 7 ohm |
| | A - C | 10 to the power of 6 ohm $< R < 10$ to the power of 7 ohm |
| | B - C | 10 to the power of 2 ohm $< R < 10$ to the power of 7 ohm |
| BAD | A - B | R < 10 to the power of 7 ohm re-inspect |
| | B - C | R < 10 to the power of 7 ohm replace wrist strap |