

STATCLEAN TECHNOLOGY (S) PTE. LTD.

30 Kaki Bukit Road 3, # 03-12/13/14, Empire Technocentre, Singapore 417819. Tel: 65-6746 2706 Fax: 65-6746 3045 / 65-6746 3755 Email: sales@statclean.com Website: www.statclean.com

Grounding Cord (STGS-15FT/SH, STGS-15/LUG)

Features:

Soft cable that prevents cracking or breaks Easy to install on ESD mats Reliable and Economical

Easy attachment to ground



Recommended to use with:

STATCLEAN 2 Layers ESD Table Mat

Shell Type:	Molded 10mm male snap button for effective and easy
	installation onto ESD mats
Cord:	Polyurethane cable (6ft, 8ft, 12ft or 15ft) with 4mm
	banana jack, alligator clip OR ring lug at one end.
	Construction: 7 strands of copper tinsel with polyester core
	One meg ohm series resistor at snap end for safety
	Snap stud also available in 7mm and 4mm
Color:	Black
Application:	Ideal for effective grounding of ESD mats
Options:	Available in shell type, dual operator or normal stud design