

STATCLEAN TECHNOLOGY (S) PTE. LTD.

30 Kaki Bukit Road 3, # 03-12/13/14, Empire Technocentre, Singapore 417819. Tel: 65-6746 2706 Fax: 65-6746 3045 / 65-6746 3755 Email: sales@statclean.com Website: www.statclean.com

Retractable Nozzle Vacuum Sealer (STSCE-AVS20) Model: AVS-20



Our Vacuum Sealer is the choice sealer for the widest range of clientele, from medical and electronics device manufacturers, to food industry retailers, to pharmaceutical and aerospace corporations

The Vacuum Sealer's 1/4" wide sealing element delivers a leak-proof seal for electronic devices that require moisture barrier bags. With one touch of the pedal the automated stainless steel nozzle retracts, and your sensitive components are sealed in seconds. Clean Room compatible, the Vacuum Sealer is also ideal for dry packaging applications on trays, tape and reel, tubes and a variety of SMD shipping containers. Combine the Vacuum Sealer's precise automation with speed, extensive safety features and incredible durability, and faulty seals resulting from operator or machine error are virtually eliminated. Compressed (shop) air is needed to operate this sealer.

Specification:

Seal Length	: 20"
Seal Width	: 1/4"
Vacuum Flow	: 6CFM
Max Vacuum Pressure	: 27inHg
Air Requirements	: 6 CFM @ 90PSI
Power Requirement	: 120/240V AC, 10 Amp during heat cycle only
Unit Size	: 28" L x 10" W x 7"H
Approximate Weight	: 32 lbs.