

STATCLEAN TECHNOLOGY (S) PTE. LTD.

30 Kaki Bukit Road 3, # 03-12/13/14, Empire Technocentre, Singapore 417819. Tel: 65-6746 2706 Fax: 65-6746 3045 / 65-6746 3755 Email: sales@statclean.com Website: www.statclean.com

Wrist Strap Footwear Tester (STME-COMBI) Model: WSFT-01

Wrist Strap & ESD foot wears are the first line of defence against electrostatic charges build up on the human body. It is designed to carry away this charge as soon as it is generated. At the same time wrist strap/foot wear must remain electrically safe for the user. Thus, it is important to test every wrist strap/footwear regularly. In order to protect the sensitive electronic components the maximum wrist strap resistance should not more than 10 Meg ohms and foot wears resistance should not more than 100 Meg ohms. On the other end, the resistance should not be less than 0.75 Meg ohms as protection to the wearer from dangerous level of the voltage and current flow. The wrist strap and the footwear tester checks these parameters under actual operating conditions with the strap on the wrist or foot wear on the foot. It clearly indicates whether or not the resistance the wrist strap/foot wear system including the wearer is at least 0.75 Meg ohms and not more than 10/100 Meg ohms respectively.

SPECIFICATIONS:

Range:	Wrist strap 0.75 to 10 Meg ohms
	Foot Wear 0.75 to 100 Meg ohms
Range Selection:	By slide switch
Indications:	Pass - GREEN LED
	LOW & High fail - RED LED (With Alarm)
Test actuation:	By Pressing metal sensor plate
Accuracy:	+/- 10%
Power supply:	9 Volt Battery
Battery Status:	By dual color LED.
Dimensions:	135 x 70 x 25 mm
Weight:	App. 150Gms with battery
Calibration:	Recommended every 12 months
Warranty:	12 Months
Optional:	Instruction Board, Foot Plate, Carry Case & Door Access System