

STATCLEAN TECHNOLOGY (S) PTE. LTD.

30 Kaki Bukit Road 3, # 03-12/13/14, Empire Technocentre, Singapore 417819. Tel: 65-6746 2706 Fax: 65-6746 3045 / 65-6746 3755 Email: sales@statclean.com Website: www.statclean.com

ESD Wrist Strap (STWS-8FT/ECON)

The adjustable wrist strap is an economical and effective way to provide proper grounding of personnel at work. The elastic wristband consists of electrically conductive materials with 7 strands of copper tinsels in the PU coil cord for prolonged durability and performance assurance. The soft and broad elastic band promotes comfort level after long hours of work.

Wrist Band: High performance elastic conductive cloth woven with

conductive fiber.

Coil Cord: Polyurethane cable (8ft) with 4mm banana jack and

alligator clip at one end;

Molded 10mm snap stub at the other end;

One meg ohm series resistor at snap end for safety

Color: Sky Blue

Size: Adjustable and elastic to fit all sizes

Static Discharge time: 0.1 second

Static Discharge time: 10^5

Application: Electronic assembly lines, Aerospace industry,

Automotive industry